



ANTI/Foam CR-D

Product Description

ANTI/Foam CR-D is a non-silicon foam control agent formulated to inhibit foaming associated with photopolymer developing and stripping. ANTI/Foam CR-D disperses extremely quickly in aqueous applications for improved antifoam performance.

Performance Features

- ANTI/Foam CR-D does not contain silica, fumed silica, or silicone.
- ANTI/Foam CR-D can be employed in both developing and resist stripping applications.
- ANTI/Foam CR-D is compatible with nearly all types of plastics and elastomers.
- ANTI/Foam CR-D is free rinsing virtually eliminating residue on process equipment.

Physical Specifications

Physical State	Liquid
Appearance	Transparent Solution
Odor	None
Freeze/Thaw Stability	Stable
Specific Gravity	1.0
Flash Point	> 160°F

Equipment Requirements

Tanks: PVC, Polyethylene, Polypropylene, Quartz, Teflon, Koroseal, (Or Tanks Lined With These Material), Steel, Monel, Or Titanium.

Heaters: Quartz, Titanium, Stainless Steel, Or Teflon-Encased Steel.

Racks: Stainless Steel And/Or Copper

Racks Coated With Plastisol Or PVC.

Delivery System: Pump Heads Should Be Constructed Of Stainless Steel, Steel, Brass, Teflon, Polycarbonate, Or Polyethylene.

Delivery Tubing Should Be Latex Or Tygon.

Product Make-Up

For most applications, ANTI/Foam CR-D is effective at concentrations of 0.005 - 0.01% by weight of the system. Additions of ANTI/Foam CR-D should only be made when the foam head of the system is unacceptable. Use the following calculation to determine the approximate volume (in milliliters) of ANTI/Foam CR-D to add to the system.

Calculation

Volume of system in gallons x 3.14 = ml of CR-D to add

NOTE: This calculation assumes the system exhibits an average weight of 8.7 pounds per gallon.

Operating Parameters

The performance of ANTI/Foam CR-D is unaffected by typical operating temperatures (60-180°F). Additions should be made to 100-ml/100 gallon of working bath. Make additions as infrequently as is necessary to prevent foam.

Control and Replenishment

ANTI/Foam CR-D should be employed at the lowest concentration, which effectively eliminates foam from the system. This volume may be different with different types of dry films or LPISMs. It is recommended that no more than 500 ml of ANTI/Foam CR-D per 100 gallons of bath be added at any one time. Additions should only be made as required to control foaming. If automated additions are desired, the following general guidelines should be employed.





Technical Data Sheet

DEVELOPING

Add ANTI/Foam CR-D at a rate of 4-5 ml/minute during processing. In pH-controlled feed and bleed applications, add ANTI/Foam CR-D at a rate of 15-20 ml/minute simultaneously with additions of developing solutions.

RESIST STRIPPING

Add ANTI/Foam CR-D at a rate of 6-8 ml/minute during processing. In feed and bleed control systems, add ANTI/Foam CR-D at a rate of 25-30 ml/minute simultaneously with additions of resist stripper.

Safety and Handling

Read and understand this product SDS before handling.

Waste Treatment

Individual users should verify the nature of spent solutions to assure compliance with local, state, and federal regulations. Contact Seacole for specific details and/or further waste treatment recommendations.

Ordering Information

ANTI/Foam CR-D is available in 1-gallon jugs, 5-gallon pails and 55-gallon drums.



+1 (763) 582-1140 | +1 (800) 966-2909 | 13505 Industrial Park Blvd. Plymouth, MN 55441 | [seacole.com](https://www.seacole.com)

